

GU10 RGB+CCT LED Spotlight (FUT103) MR16 RGB+CCT LED Spotlight (FUT104) [ 0201-4 ]

1 Features



RGB+CCT 16 Millions of colors to choose



Color temperature 2700~6500K



Dimmable Saturation control



2.4G RF wireless transmission technology



Signal transmitting & Modes synchronization




Remote control Control distance 30m



Smart phone APP control (2.4GHz gateway is needed)




Support third party voice control (2.4GHz gateway is needed)



### GU10 RGB+CCT LED Spotlight

Model No.: FUT103 Power: 4W Voltage: AC100~240V Working Temp.: -20~60°C Color Temp.: 2700~6500K Luminous Efficiency: 70LM/W CRI: >80 PF: 0.55 Lifespan: 50000h Beam Angle: 25° RF: 2.4GHz Transmitting Power: 6dBm Control Distance: 30m




### MR16 RGB+CCT LED Spotlight


Model No.: FUT104 Power: 4W Voltage: AC/DC12V Working Temp.: -20~60°C Color Temp.: 2700~6500K Luminous Efficiency: 70LM/W CRI: >80 Lifespan: 50000h Beam Angle: 25° RF: 2.4GHz Transmitting Power: 6dBm Control Distance: 30m

# 2. Instructions

### Step 1


Put the light bulb in the suitable lighting fixture.





### Step 2: Link/Unlink

Compatible with these remote controls (Purchased separately)





WL-Box1



Lighting can be working after linking with remote; for more details, pls read the remote instruction.

## 3. Dynamic Mode Sheet


Number	Dynamic Mode	Brightness / Saturation / Speed
1	Mardi Gras	
2	Automatic color change	
3	Sam	
4	Gemstone	
5	Twilight	Adjustable
6	American	
7	Fat Tuesday	
8	Party	
9	Slow Color Splash	

## 4. Signal transmitting

One lighting fixture can transmit the signals from the remote control to another lighting fixture within 30m, as long as there is a lighting fixture within 30m, the remote control distance can be limitless.

## 5. Modes synchronization

Different lighting fixture can work synchronously when they are started at different times, controlled by the same remote, under same dynamic mode and within 30m distance.



## 6. Attention

- 1. When install the lighting fixtures, pls switch off the power to make sure the safty.
- 2. Please check whether the input voltage supply is in accordance with the lighting fixtures.
- Non-professional user cannot dismantle the lighting fixtures directly, otherwise, it may cause fire and electric shock.
- Please do not use lighting fixtures around the mental area and high magnetic field, otherwise, it will badly affect the control distance.

